RADIO INFLUENCE VOLTAGE
vs.
APPLIED VOLTAGE

TYPE V

DEAD-END STRAIN ASSEMBLY
(CONVENTIONAL INSULATOR ARRANGEMENT)

Corona Voltage - 370 KV

June 18, 1965

RADIO INFLUENCE VOLTAGE (Microvolts)

APPLIED VOLTAGE (Kv-RMS)

0 100 200 300 400 500 600 700 800 900 1000

100 150 200 250 300 350 400 450

FIG. 12

10 X 10 TO THE ½ INCH 359-11
KEUFFEL & ESSER CO. MADE IN U.S.A.

RADIO INFLUENCE VOLTAGE
vs.
APPLIED VOLTAGE

TYPE IV
VEE STRING SUSPENSION ASSEMBLY

Corona Voltage - 364 KV

June 16, 1965

RADIO INFLUENCE VOLTAGE (Microvolts)

APPLIED VOLTAGE (Kv-RMS)

0 100 200 300 400 500 600 700 800 900 1000

100 150 200 250 300 350 400 450

FIG. 11

10 X 10 TO THE ½ INCH 359-11
KEUFFEL & ESSER CO. MADE IN U.S.A.